




**PART NO: A14131
TAMPERPROOFING KIT**



I. INSTALLATION INSTRUCTIONS:

- A. Adjust Kinechek to desired feed rate.
- B. Insert plunger assembly into cross hole in adjustment knob on end of Kinechek.
- C. Using fingers, compress plunger assembly into hole until flush with adjustment knob surface.
- D. While holding plunger assembly flush, slip tamperproof cap over end of knob and assembly. Remove fingers and push cap on until plungers snap into groove inside of the cap. partially over plunger as-
- E. Rotate Cap to insure that it rotates freely without changing the adjustment setting.

II. REMOVAL INSTRUCTIONS:

- A. Rotate tamperproof cap until the two small holes on the outer surface are aligned with the ends of the plunger assembly. Insert the ends of the removal tool into the two small holes and squeeze inward to compress the plunger and release the cap. Carefully slide the tamperproof cap partially off. The cap removal tool can then be removed (after the cap is partially removed) to allow the free hand to restrain the spring loaded plungers and prevent them from flying out when the cap is fully removed.



Deschner Corporation
3211 W. Harvard St., Santa Ana, Ca. 92704
Ph: (800) 457-6666, Fax: (714) 557-4762
Email: Deschcorp@aol.com, Web: www.deschner.com